




SPINNING REEL

SAMIRA
 X-TREME

 Please order by parts number, not key number
 Bitte, Best.-Nr. angeben (Nicht "key"-nr.)
 Veuillez indiquer le numero de la pièce (Non "key" no.)

SAAT1000H/SAAT1000
SAAT1500H/SAAT1500



Key NO.	Parts No.	Parts name	Key NO.	Parts No.	Parts name
1	2YD-124-01	DRAG KNOB ASSEMBLY	44	2E2-013-02	B20M-060 SCREW
2	2E4-030-01	DRAG WASHER RETAINER	45	2M1-023-01	OSCILLATING SLIDER
3	2W2-071-01	KEY WASHER	46	2M5-001-01	LINE GUIDE PIN
4	2W1-226-02	080-260 WASHER	47	2C2-034-01	LINE GUIDE PIN BUSH
5	2YT-580-01	SPOOL TOTAL ASSEMBLY	48	2W1-059-01	020-049 WASHER
6	2W2-016-01	KEY WASHER	49	2F5-048-01	OSCILLATING SLIDER COVER
7	2Z1-029-05	408-3 BALL BEARING	50	2E2-022-01	B20M-030 SCREW
8	2C1-119-01	SPACER	51	2W1-058-04	030-050 WASHER
9	2L3-014-01	CLICK LEAF SPRING	52	2Z1-014-05	306-2.5 BALL BEARING
10	2W1-053-02	080-185 WASHER	53	2H6-017-03	HANDLE SCREW CAP
11	2F8-013-02	CLICK LEAF SPRING HOLDER	54	2C3-042-01	HANDLE SCREW SLEEVE
12	2W2-015-01	KEY WASHER	55	2B2-153-01	BODY COVER (R)
13	2E3-007-02	ROTOR NUT	56	2B1-217-01	BODY
14	2E1-056-01	B20-035 SCREW	57	2P1-015-01	OSCILLATING SLIDER PIN
15	2R1-169-01	ROTOR	58	2C1-048-01	WORM SHAFT COLLAR
16	2E2-018-01	B30M-080 SCREW	59	2C2-058-01	WORM SHAFT BUSH
17	2R2-084-01	BAIL ARM	60	2G3-047-01	OSCILLATING GEAR
18	2W4-020-01	LINE ROLLER NUT SPACER	61	2M4-040-01	WORM SHAFT
19	2Z1-012-05	407-2.5 BALL BEARING	62	2Z1-014-05	306-2.5 BALL BEARING
20	2C1-077-01	LINE ROLLER COLLAR	63	2F5-495-01	WORM SHAFT COVER
21	2R6-022-01	LINE ROLLER	64	2E1-036-01	B26-040 SCREW
22	2YL-198-01	BAIL ASSEMBLY	65	2F6-135-01	PROOF WATER RING
23	2E1-025-01	b30-080 SCREW	66	2F5-499-01	REAR COVER
24	2R5-210-01	BAIL PAWL	67	2E1-075-01	B22-045 SCREW
25	2R5-223-01	BAIL TRIP SHAFT	68	2Z1-009-05	711-3 BALL BEARING
26	2W1-044-01	016-035 WASHER	69	2G1-056-02	DRIVE GEAR
27	2Q1-141-01	BAIL SPRING	70	2W1-019-00	071-103 WASHER
28	2R4-236-01	BAIL SPRING COVER	71	2B2-152-01	BODY COVER (L)
29	2E1-065-01	B22-065 SCREW	72	2E1-050-01	A20-060 SCREW
30	2M3-177-01	MAIN SHAFT	73	2E1-055-01	A26-100 SCREW
31	2W1-019-05	071-103 WASHER	74	2YH-521-01	HANDLE TOTAL ASSEMBLY
32	2E1-050-01	A20-060 SCREW	SAAT1000 SPECIAL PARTS		
33	2F5-517-01	ROLLER CLUTCH RETAINER	5	2YT-580-02	SPOOL TOTAL ASSEMBLY
34	2Z1-003-05	714-5 BALL BEARING	39	2G2-036-01	PINION GEAR
35	2C1-144-01	BUSHING	60	2G3-012-01	WORM SHAFT GEAR
36	2A4-095-01	ONE-WAY CLUTCH INNER TUBE	69	2G1-003-02	DRIVE GEAR
37	2YZ-034-01	ONE-WAY CLUTCH BEARING ASSEMBLY	SAAT1500H SPECIAL PARTS		
38	2Q2-024-01	SPRING	5	2YT-538-01	SPOOL TOTAL ASSEMBLY
39	2G2-073-01	PINION GEAR	SAAT1500 SPECIAL PARTS		
40	2Q3-129-01	ANTI-REVERSE SPRING	5	2YT-538-02	SPOOL TOTAL ASSEMBLY
41	2A2-123-01	ANTI-REVERSE CAM	39	2G2-036-01	PINION GEAR
42	2E2-099-01	B20M-050 SCREW	60	2G3-012-01	WORM SHAFT GEAR
43	2A1-041-01	ANTI-REVERSE LEVER	69	2G1-003-02	DRIVE GEAR




SPINNING REEL

SAMIRA
 X-TREME

 Please order by parts number, not key number
 Bitte, Best-Nr. angeben (Nicht "key" -nr.)
 Veuillez indiquer le numero de la pièce (Non "key" no.)

SAAT3000H/SAAT3000
SAAT3500H/SAAT3500


Key NO.	Parts No.	Parts name	Key NO.	Parts No.	Parts name
1	2YD-116-01	DRAG KNOB ASSEMBLY	50	2Z1-005-05	816-5 BALL BEARING
2	2E4-040-01	DRAG WASHER RETAINER	51	2G2-192-01	PINION GEAR
3	2W2-088-02	KEY WASHER	52	2C2-049-01	WORM SHAFT BUSH C
4	2W1-263-02	070-285 WASHER	53	2G3-031-01	OSCILLATING GEAR
5	2W3-041-01	EARED WASHER	54	2M4-018-01	WORM SHAFT
6	2S1-438-01	SPOOL	55	2W1-058-03	030-050 WASHER
7	2S4-019-01	LINE STOPPER	56	2Z1-014-05	306-2.5 BALL BEARING
8	2Q3-121-01	SPRING	57	2E2-009-02	F23M-060 SCREW
9	2S5-063-01	BOTTOM SPOOL	58	2M1-032-01	OSCILLATING SLIDER
10	2YT-532-01	SPOOL TOTAL ASSEMBLY	59	2W1-058-02	030-050 WASHER
11	2W2-014-01	KEY WASHER	60	2M5-007-01	LINE GUIDE PIN
12	2Z1-013-05	610-3 BALL BEARING	61	2C2-034-01	LINE GUIDE PIN BUSH
13	2C1-139-01	COLLAR SPACER	62	2W1-058-04	030-050 WASHER
14	2L3-014-01	CLICK LEAF SPRING	63	2F5-181-01	OSCILLATING SLIDER COVER
15	2W1-053-02	080-185 WASHER	64	2H6-017-03	HANDLE SCREW CAP
16	2F8-013-02	CLICK LEAF SPRING HOLDER	65	2C3-042-01	HANDLE SCREW SLEEVE
17	2W2-024-01	KEY WASHER	66	2B2-150-01	BODY COVER (R)
18	2M3-173-01	MAIN SHAFT	67	2B1-215-01	BODY
19	2E3-094-01	ROTOR NUT	68	2Z1-010-05	812-3.5 BALL BEARING
20	2E1-036-01	B26-040 SCREW	69	2G1-057-02	DRIVE GEAR
21	2C1-135-01	PINION GEAR BUSH	70	2W1-035-00	080-105 WASHER
22	2R1-166-01	ROTOR	71	2Z1-023-05	814-4 BALL BEARING
23	2E2-018-01	B30M-080 SCREW	72	2B2-149-01	BODY COVER (L)
24	2R2-081-01	BAIL ARM	73	2E1-009-01	A30-100 SCREW
25	2W4-020-01	LINE ROLLER NUT SPACER	74	2E1-045-01	A26-080 SCREW
26	2Z1-012-05	407-2.5 BALL BEARING	75	2YH-500-01	HANDLE TOTAL ASSEMBLY
27	2C1-077-01	LINE ROLLER COLLAR	76	2P1-025-01	OSCILLATING SLIDER PIN
28	2R6-022-01	LINE ROLLER	77	2W5-031-01	WORM SHAFT COVER GASKET
29	2C1-120-01	COLLAR	78	2F5-161-01	WORM SHAFT COVER
30	2YL-192-01	BAIL ASSEMBLY	79	2W1-124-02	045-065 WASHER
31	2E1-025-01	b30-080 SCREW	80	2E1-069-01	A20-045 SCREW
32	2R5-188-01	BAIL TRIP SHAFT	81	2F6-134-01	PROOF WATER RING
33	2W1-044-01	016-035 WASHER	82	2F5-490-01	REAR COVER
34	2Q1-132-02	BAIL SPRING	83	2E1-075-01	B22-045 SCREW
35	2R5-207-01	BAIL PAWL			
36	2R4-232-01	BAIL SPRING COVER	SAAT3000 SPECIAL PARTS		
37	2E1-015-02	B26-060 SCREW	6	2S1-438-02	SPOOL
38	2E1-048-01	B22-080 SCREW	10	2YT-532-02	SPOOL TOTAL ASSEMBLY
39	2Q3-009-01	ANTI-REVERSE SPRING	51	2G2-193-01	PINION GEAR
40	2F8-079-01	ANTI-REVERSE SPRING ANCHOR	53	2G3-018-01	OSCILLATING GEAR
41	2A2-122-01	ANTI-REVERSE CAM	69	2G1-010-02	DRIVE GEAR
42	2F5-189-01	ROLLER CLUTCH RETAINER	SAAT3500H SPECIAL PARTS		
43	2A1-040-01	ANTI-REVERSE LEVER	6	2S1-439-01	SPOOL
44	2E2-099-01	B20M-050 SCREW	10	2YT-533-01	SPOOL TOTAL ASSEMBLY
45	2Q2-016-01	SPRING	SAAT3500 SPECIAL PARTS		
46	2YZ-017-01	ONE-WAY CLUTCH BEARING ASSEMBLY	6	2S1-439-02	SPOOL
47	2A4-026-01	ONE-WAY CLUTCH INNER TUBE	10	2YT-533-02	SPOOL TOTAL ASSEMBLY
			51	2G2-193-01	PINION GEAR



Key NO.	Parts No.	Parts name	Key NO.	Parts No.	Parts name
1	2YD-116-01	DRAG KNOB ASSEMBLY	50	2Z1-005-05	816-5 BALL BEARING
2	2E4-040-01	DRAG WASHER RETAINER	51	2G2-192-01	PINION GEAR
3	2W2-088-02	KEY WASHER	52	2C2-049-01	WORM SHAFT BUSH C
4	2W1-263-02	070-285 WASHER	53	2G3-031-01	OSCILLATING GEAR
5	2W3-041-01	EARED WASHER	54	2M4-018-01	WORM SHAFT
6	2S1-438-01	SPOOL	55	2W1-058-03	030-050 WASHER
7	2S4-019-01	LINE STOPPER	56	2Z1-014-05	306-2.5 BALL BEARING
8	2Q3-121-01	SPRING	57	2E2-009-02	F23M-060 SCREW
9	2S5-063-01	BOTTOM SPOOL	58	2M1-032-01	OSCILLATING SLIDER
10	2YT-532-01	SPOOL TOTAL ASSEMBLY	59	2W1-058-02	030-050 WASHER
11	2W2-014-01	KEY WASHER	60	2M5-007-01	LINE GUIDE PIN
12	2Z1-013-05	610-3 BALL BEARING	61	2C2-034-01	LINE GUIDE PIN BUSH
13	2C1-139-01	COLLAR SPACER	62	2W1-058-04	030-050 WASHER
14	2L3-014-01	CLICK LEAF SPRING	63	2F5-181-01	OSCILLATING SLIDER COVER
15	2W1-053-02	080-185 WASHER	64	2H6-017-03	HANDLE SCREW CAP
16	2F8-013-02	CLICK LEAF SPRING HOLDER	65	2C3-042-01	HANDLE SCREW SLEEVE
17	2W2-024-01	KEY WASHER	66	2B2-150-01	BODY COVER (R)
18	2M3-173-01	MAIN SHAFT	67	2B1-215-01	BODY
19	2E3-094-01	ROTOR NUT	68	2Z1-010-05	812-3.5 BALL BEARING
20	2E1-036-01	B26-040 SCREW	69	2G1-057-02	DRIVE GEAR
21	2C1-135-01	PINION GEAR BUSH	70	2W1-035-00	080-105 WASHER
22	2R1-166-01	ROTOR	71	2Z1-023-05	814-4 BALL BEARING
23	2E2-018-01	B30M-080 SCREW	72	2B2-149-01	BODY COVER (L)
24	2R2-081-01	BAIL ARM	73	2E1-009-01	A30-100 SCREW
25	2W4-020-01	LINE ROLLER NUT SPACER	74	2E1-045-01	A26-080 SCREW
26	2Z1-012-05	407-2.5 BALL BEARING	75	2YH-500-01	HANDLE TOTAL ASSEMBLY
27	2C1-077-01	LINE ROLLER COLLAR	76	2P1-025-01	OSCILLATING SLIDER PIN
28	2R6-022-01	LINE ROLLER	77	2W5-031-01	WORM SHAFT COVER GASKET
29	2C1-120-01	COLLAR	78	2F5-161-01	WORM SHAFT COVER
30	2YL-192-01	BAIL ASSEMBLY	79	2W1-124-02	045-065 WASHER
31	2E1-025-01	b30-080 SCREW	80	2E1-069-01	A20-045 SCREW
32	2R5-188-01	BAIL TRIP SHAFT	81	2F6-134-01	PROOF WATER RING
33	2W1-044-01	016-035 WASHER	82	2F5-490-01	REAR COVER
34	2Q1-132-02	BAIL SPRING	83	2E1-075-01	B22-045 SCREW
35	2R5-207-01	BAIL PAWL	SAAT4000 SPECIAL PARTS		
36	2R4-232-01	BAIL SPRING COVER	6	2S1-444-02	SPOOL
37	2E1-015-02	B26-060 SCREW	10	2YT-541-02	SPOOL TOTAL ASSEMBLY
38	2E1-048-01	B22-080 SCREW	51	2G2-193-01	PINION GEAR
39	2Q3-009-01	ANTI-REVERSE SPRING	53	2G3-018-01	OSCILLATING GEAR
40	2F8-079-01	ANTI-REVERSE SPRING ANCHOR	69	2G1-010-02	DRIVE GEAR
41	2A2-122-01	ANTI-REVERSE CAM	SAAT4500H SPECIAL PARTS		
42	2F5-189-01	ROLLER CLUTCH RETAINER	6	2S1-445-01	SPOOL
43	2A1-040-01	ANTI-REVERSE LEVER	10	2YT-542-01	SPOOL TOTAL ASSEMBLY
44	2E2-099-01	B20M-050 SCREW	SAAT4500 SPECIAL PARTS		
45	2Q2-016-01	SPRING	6	2S1-445-02	SPOOL
46	2YZ-017-01	ONE-WAY CLUTCH BEARING ASSEMBLY	10	2YT-542-02	SPOOL TOTAL ASSEMBLY
47	2A4-026-01	ONE-WAY CLUTCH INNER TUBE	51	2G2-193-01	PINION GEAR
48	2E1-068-01	F30-100 SCREW	53	2G3-018-01	OSCILLATING GEAR
49	2F5-203-01	BEARING RETAINER	69	2G1-010-02	DRIVE GEAR

