



Key No	Parts No.	Parts name	Key No	Parts No.	Parts name
1	2YD-021-04	DRAG KNOB ASSEMBLY	29	2Z1-008-05	1020-5 BALL BEARING
2	2E4-003-01	DRAG WASHER RETAINER	30	2G2-057-01	PINION GEAR
3	2W2-048-01	KEY WASHER	31	2E1-018-01	G30-100 SCREW
4	2W1-175-01	100-300 WASHER	32	2E1-057-01	B30-130 SCREW
5	2W3-027-01	EARED WASHER	33	2A4-062-01	ANTI-REVERSE PAWL
6	2YT-337-04	SPOOL TOTAL ASSEMBLY	34	2Q3-045-01	ANTI-REVERSE PAWL SPRING
7	2W2-011-01	KEY WASHER	35	2B1-125-04	BODY
8	2F3-021-01	CLICK GEAR	36	2Z1-007-05	917-4 BALL BEARING
9	2M3-107-01	MAIN SHAFT	37	2G1-052-02	DRIVE GEAR
10	2E3-003-01	ROTOR NUT	38	2W1-014-00	091-130 WASHER
11	2E1-019-01	D26-060 SCREW	39	2G3-064-01	OSCILLATING GEAR
12	2R1-114-04	ROTOR	40	2C1-089-01	COLLAR
13	2E2-007-01	B30M-100 SCREW	41	2M2-011-01	OSCILLATING CAM
14	2R2-048-04	BAIL ARM	42	2W5-062-01	COVER
15	2C1-049-01	LINE ROLLER COLLAR	43	2E1-063-01	F26-070 SCREW
16	2Z1-001-05	508-2.5 BALL BEARING	44	2M1-052-01	OSCILLATING SILDER
17	2R6-018-01	LINE ROLLER	45	2E2-011-01	F30M-080 SCREW
18	2C1-068-01	COLLAR	46	2A2-082-01	ANTI-REVERSE CAM
19	2YL-116-04	BAIL ASSEMBLY	47	2L5-012-01	ANTI-REVERSE CAM SPRING
20	2E1-014-01	B40-100 SCREW	48	2A1-022-07	ANTI-REVERSE LEVER
21	2Q3-105-01	BAIL SPRING	49	2E2-013-02	B20M-060 SCREW
22	2R4-146-02	BAIL SPRING COVER	50	2B2-082-04	BODY COVER
23	2E1-011-01	B30-100 SCREW	51	2E1-006-02	A30-130 SCREW
24	2R5-125-01	BAIL TRIP LEVER	52	2YH-644-01	HANDLE TOTAL ASSEMBLY
25	2R4-145-02	BAIL TRIP COVER	53	2C3-047-01	HANDLE SCREW SLEEVE
26	2F1-008-02	SPRING HOLDER	54	2H6-002-01	HANDLE SCREW CAP
27	2Q3-050-01	ANTI-REVERSE PAWL SPRING	BW8000	SPECIAL PARTS	
28	2F3-023-01	CLICK GEAR	6	2YT-340-04	SPOOL TOTAL ASSEMBLY